






Poly Studio Display Mounting Kit

Top of Display


Haut de l'écran
Display, unten
Parte superior de la pantalla
Parte superiore del display
Parte superior da tela
Góra ekranu
Kijelző teteje
Toppen av displayet
ディスプレイの上部
디스플레이 상단
显示屏顶部
顯示器頂部




4 VESA Mounting Options



5 Attach the Poly Studio mounting kit assembly to the display using the appropriate screws and washers for your display.



6







Bottom of Display

Bas de l'écran
Display, oben
Parte inferior de la pantalla

Parte inferiore del display
Parte inferior da tela
Dół ekranu

Kijelző alja
Bunnen av displayet
ディスプレイの下部

디스플레이 하단
显示屏底部
顯示器底部



5 VESA Mounting Options

